

INTERNATIONAL STANDARD

ISO
23251

First edition
2006-08-15

AMENDMENT 1
2008-05-01

Petroleum, petrochemical and natural gas industries — Pressure-relieving and depressuring systems

AMENDMENT 1

*Industries du pétrole, de la pétrochimie et du gaz naturel — Systèmes
de dépressurisation et de protection contre les surpressions*

AMENDEMENT 1



Reference number
ISO 23251:2006/Amd.1:2008(E)

© ISO 2008

PDF disclaimer

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.



COPYRIGHT PROTECTED DOCUMENT

© ISO 2008

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

Amendment 1 to ISO 23251:2006 was prepared by Technical Committee ISO/TC 67, *Materials, equipment and offshore structures for petroleum, petrochemical and natural gas industries*, Subcommittee SC 6, *Processing equipment and systems*.

STANDARDSISO.COM : Click to view the full PDF of ISO 23251:2006/Amd 1:2008

Petroleum, petrochemical and natural gas industries — Pressure-relieving and depressuring systems

AMENDMENT 1

Page 50, 5.15.7.4

Replace the last sentence at the end of subclause, "In calculating the heat absorption... wetted area term." with the following:

In calculating the heat absorption due to fire exposure, use Equations (6) and (7), applying an exponent of 1,0 to the wetted area term along with the following values of C_1 and C_2 :

In SI units:

$$C_1 = 66\,300$$

$$C_2 = 108\,900$$

In USC units:

$$C_1 = 21\,000$$

$$C_2 = 34\,500$$

Page 65, Clause 5

Add a new subclause, **5.23**, after **5.22**:

5.23 Overfilling process or surge vessel

5.23.1 General

Many process or surge vessels, including columns and towers, have a liquid level present during normal, start-up, or shutdown conditions. Experience has shown that this equipment can be overfilled under certain conditions. If the source pressure of a liquid feed or supply line can exceed the relief device set pressure and/or the design pressure of the equipment, then overfilling shall be included in the system design. System design options to deal with liquid overfill include but are not limited to

- a) increasing the system design pressure and/or pressure relief device set pressure within pressure design code allowances,
- b) designing a pressure-relief system that can safely accommodate the overfill (including the effects of operator intervention response as discussed in 5.4),
- c) installing a safety instrumented system (SIS) to prevent the liquid overfill.

For all three options, all phases of operation shall be evaluated. Particular attention shall be given to start-up and other non-routine operations where process conditions (e.g., flow rates, temperature and density) can be different from normal and where conditions that lead to overfilling can be more likely to occur when compared with normal operations.

If option a) is chosen, the user shall validate the design (foundation, piping, etc.) consistent with the liquid overfill scenario.

If option b) is chosen, the user shall select the pressure-relief devices, design their inlet and outlet piping, validate the foundation design, etc. consistent with the liquid overfill scenario. If operator intervention is used as part of the system design, then the risk of failure of the operator to properly intervene shall be addressed. The pressure-relief device may discharge back into a disposal system, such as a lower-pressure section of the process, a flare or to other disposal system. If it is a basis for the disposal-system design, then the user shall consider liquid overfill when designing the knockout drum, collection headers, etc. The design of the disposal system shall prevent the discharge of liquids above their flash point directly to atmosphere (into the air or on the ground) if there is an unacceptable risk as a result of a vapour-cloud explosion or other hazardous condition. See 6.3.2.4 for cautions regarding the atmospheric discharge of liquids. See 6.6 regarding options for the disposal of liquids.

5.23.2 Mitigation measures

When designing the system to mitigate liquid overfill, the following can affect the design and shall be evaluated:

- a) risk of failure of the operator to respond properly;
- b) operator training and operating procedures that include instrumentation behaviour;

EXAMPLE If a differential-pressure or displacer-level measurement reads low compared to actual level when the fluid specific gravity is less than the design gravity. This can mean that the indicated level cannot reach 100 % even if the actual level is well above the measured range.

- c) availability of instrumentation that is required for adequate operator intervention;
- d) availability of instrumentation that is required for safety instrumented system (SIS) response;
- e) potential consequence associated with relief-stream disposition (e.g., discharge back into the process, discharge to atmosphere, discharge to a treatment system, such as a flare, etc.);
- f) pressure design code requirements.

If operator intervention and/or SIS options are selected, then a risk analysis method shall determine the adequacy of the protection.

5.23.3 Level instruments

Some criteria to consider when evaluating level instrumentation and alarms to demonstrate availability and independence from the basic process control system include the following:

- a) whether the level instruments used for safeguards against overfilling are on separate process taps from the process control system;
- b) whether level instruments used for safeguards against overfilling are susceptible to the same common mode device failures as those used for the basic process control system. Diverse instrumentation can minimize the potential for common-mode device failures (e.g., differential pressure and radar, displacer and float, etc.);
- c) whether the instruments are proven in use for the specific process applications;

- d) whether the range of at least one of the level measurement(s) can indicate a valid level reading over the full range between the high critical alarm point and any shutdown or interlock point;
- e) whether operating characteristics of the level measurement during off-design, start-up and shutdown operations are considered in the display of level, setting alarms, trip points, operator training and operating procedures.

Page 96, 6.6.2.3

Add the following paragraph at the end of 6.6.2.3 a):

Sizing of the quench drum is discussed in 7.3.2.3.2. In addition to the quenching of vapours, the drum is typically required to provide vapour-liquid separation, liquid retention and disposal. If the quench drum is part of a header network consisting of multiple relief devices or tie-ins, then see 6.7 and 7.3.4 for additional design guidance.

Page 97, Clause 6

Add a new subclause, 6.7, after 6.6.5:

6.7 Disposal through common vent stack

The general principles in 6.3 also apply to designs involving multiple relief devices discharging into a common header manifold that is either vented directly to atmosphere through a common vent stack or through a separator, quench, blowdown, scrubber or other drum where liquid is collected and the vapour is discharged through a common vent stack. In particular, the considerations that it is necessary to evaluate for these systems shall include the following:

- a) guidance on determining design loads is given in 7.1;
- b) relief manifold system design is discussed in 7.2.3 and 7.3.1.3;
- c) guidance on liquid disposal options is given in 5.23 and 6.6.

Because these systems can encounter a wide range of relief loads, consequence assessment shall evaluate both the scenarios representing the design loads but also smaller releases that result in a lower discharge velocity and, consequently, a greater tendency for the plume to drop to grade level in a hazardous concentration. Guidance on the specification and location of the vent stack is given in 7.3.4. Note that the guidance in 6.3.2 applies only to individual relief device tail pipes that discharge to atmosphere.

CAUTION — If there is a vapour-cloud explosion hazard associated with one or more relief cases or discharges, then one of the following shall be used:

- disposal by a flare (see 6.4);
- discharging into a lower pressure system (see 6.5);
- application of HIPS (see Annex E);
- eliminating the relevant relief cases (redesign of equipment, etc.).

The user shall assess hazards other than a vapour-cloud explosion associated with the release and determine appropriate mitigation measures.

Page 115, 7.3.2.1

Change title from “Knockout drums” to “Flare knockout drums”

Page 117, 7.3.2.1.2, below Equation (39)

Replace the units for μ , “expressed in megapascal-seconds (centipoise)”; with “expressed in millipascal-seconds (centipoise);”

Page 118, 7.3.2.1.2

Replace the paragraph following 7.3.2.1.2 b), “The volume occupied....vapour disengagement.”, with the following:

The volume occupied by the liquid should be based on a release that lasts 20 min to 30 min. A larger hold-up volume can be required if it takes longer to stop the flow. Any accumulation of liquid retained from a prior release (from pressure-relief devices or other sources) should be added to the liquid indicated in items 6.7 a) and 6.7 b) to determine the available vapour-disengaging space.

The risk of overfilling the flare knockout drum shall be assessed. Most flares are not designed to effectively combust liquid. These evaluations should consider the effect of

- the amount of liquid in the knockout drum prior to the release including the removal time,
- the liquid weight on the flare header and the flare stack mechanical integrity,
- the discharge of liquid from the flare (i.e., potential for flame-out, excessive smoke and unburned hydrocarbon emissions, discharge of “burning rain”, pool fires around the flare stack, etc.);
- the flare siting/location in proximity to areas where people can be exposed, to property fence-lines, units, etc.

Page 127, 7.3.2.3

Replace the title and text of 7.3.2.3, “Sizing a quench drum” with the following:

7.3.2.3 Knockout drums venting to atmosphere

7.3.2.3.1 General

Atmospheric blowdown systems are knockout drums with stacks open to atmosphere.

CAUTION — If there is a vapour-cloud explosion hazard associated with one or more relief cases or discharges, then one of the following shall be used:

- disposal by a flare (see 6.4);
- discharging into a lower pressure system (see 6.5);
- application of HIPS (see Annex E);
- eliminating the relevant relief cases (redesign of equipment, etc.).

The user shall assess hazards other than a vapour-cloud explosion associated with the release and determine appropriate mitigation measures.

The criteria in 7.3.2.3.2 and 7.3.2.3.3 can be used to design atmospheric knockout drums for releases that have no vapour cloud explosion hazard.

7.3.2.3.2 Atmospheric knockout drums (without quench provisions)

All of the following criteria shall be met.

- a) The design of the atmospheric knockout drum shall meet the design criteria for flare knockout drums in 7.3.2.1.
- b) The atmospheric knockout drum shall be designed to knock out liquid droplets such that any remaining droplets or the plume cannot reach working areas, property lines or other critical areas at a hazardous concentration. The droplet size criteria for atmospheric knockout drums should be more stringent than for flare knockout drums (See 7.3.2.1) because most flares are capable of burning small droplets [151].
- c) See 7.3.4 for design guidance on the vent stack.

7.3.2.3.3 Atmospheric knockout drums (with quench provisions)

In 7.3.2.3.3 is considered the design of the atmospheric knockout drums with a quench provision (e.g., quench drum) where the quench liquid is water that cools and/or condenses the released material. The design of drums where the quench liquid is not water or where quenching non-petrochemical releases can use the principles given below but can require additional or different considerations.

All of the following criteria shall be met.

- a) The design of the quench drum shall meet the design criteria for flare knockout drums in 7.3.2.1. In general, a vertical cylindrical vessel is preferred.
- b) The quench drum shall have a liquid-removal system capacity equal to the maximum quench water supply plus condensed and/or liquid hydrocarbons. If backup quench is required, as per item h) below, then the liquid-removal system shall be sized to handle the maximum flow from both sources of quench along with the maximum condensed release flow. No valves shall be provided in the gravity drain line.
- c) If a gravity drain is used, then the quench drum should have a liquid holdup that is sufficient to create the static head necessary to push the liquid out of the gravity drain at the rate required by b) but not reach the bottom of the contactors as shown in Figure D.2.
- d) Water requirements are normally based on reducing gas and liquid outlet temperatures. Selection of the optimum temperature is based on considerations of the temperature and composition of entering streams, the extent to which subsequent condensation of effluent vapours downstream of the drum can be tolerated, and the maximum temperature limitations of the disposal system (e.g., sewer).
- e) The maximum temperature in the quench-drum reservoir shall be selected to avoid the drying out of the drum and losing the liquid seal. Some margin shall be provided to stay below the local atmospheric boiling temperature.
- f) The water holdup in the base of the drum shall be sized to absorb the maximum heat of the release for a sufficient amount of time for the quench to be fully established.
- g) The water supply shall be reliable. If a fixed basin of water is used, then the basin shall have adequate capacity to supply the maximum condensable quench requirement for 30 min.
- h) The quench water shall be automatically actuated by high temperature or flow in the inlet line. The availability (SIL level) of the quench water system shall be determined (see E.4.2). An emergency backup water connection can be required to achieve the necessary SIL level. Possible consequences from failure of the quench water, resulting in release of excessive vapours to atmosphere and/or hot liquids to the sewer, shall be considered.
- i) A continuous make-up water supply shall be provided to maintain the outlet seal.